

SONY ALPHA a5100

USE AC ADAPTER INSTEAD OF BATTERY
NO SD CARD NEEDED



HDMI MICRO

Canon VIXIA HF R800

PLUG IN CHARGER
NO SD CARD NEEDED



HDMI MINI

Canon VIXIA HF R800

PLUG IN CHARGER
NO SD CARD NEEDED



HDMI MINI

LAPTOP

SETUP DUPLICATE DISPLAY



HDMI

Blue Yeti USB Microphone

USB PLUGGED INTO AC
CHARGER



MIC 1

HDMI 1

HDMI 2

HDMI 3

HDMI 4

HDMI OUT

USB C WEBCAM OUT



Blackmagic Design ATEM Mini Pro
HDMI Live Stream Switcher

Blackmagic Design Video Assist

HDMI/6G-SDI
Recorder and 5" Monitor



HDMI IN

OPTIONAL PC FOR
LIVESTREAM

